

TICKET MACHINE ENTRANCE SYSTEM FUNCTION:

A vehicle crossing the arming loop either causes a ticket to be issued or arms the push button for ticket issue. When the patron removes the ticket from the ticket machine, the gate arm will open permitting the vehicle to enter the facility. When the vehicle leaves the closing loop, the gate arm will close.

POWER REQUIREMENTS: 120 VAC, 60 Hz, 20 AMPS

EQUIPMENT: TICKET MACHINE, PARKING GATE, (2) LOOP DETECTORS

